

DISCOVERY MANUAL

FOR M.P.H. CLOCKS KEEP TRIP BUTTON PRESSED UNTIL MILEAGE CHANGES TO KILOMETER.

TAKE CLOCK OUT, REMOVE BACK COVER. LIFT CIRCUIT BOARD OFF. THE EEPROM 93C56 WILL BE VISIBLE ON OTHER SIDE. PROGRAMME MILEAGE. (IN KILOMETER)

BODY CONTROLLER

THE BODY CONTROLLER IS BEHIND THE GLOVE BOX.

OPEN GLOVE BOX. UNCLIP BRACKET, SO GLOVE BOX DROPS ALL THE WAY TO THE FRONT.

THE BODY CONTROLLER IS ON THE LEFT, WHICH HAS A BOLT GOING THROUGH IT. UNDO BOLT. THERE ARE PLUGS UNDERNEATH AND ONE TO THE SIDE. UNDO ALL PLUGS PULL OUT UNIT.

WHILE UNIT IS OUT, PUT CLOCK BACK IN. WHATEVER THE NEW MILEAGE IS DISPLAYED YOU MUST PUT THE SAME IN THE BODY CONTROLLER.