

Daewoo **V25.00** Diagnostics List(Note:For reference only)

Vehicles	System	Sub System	functions						
			System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID	Special Functions
LEMANS(RACER)	ENGINE SOHC	1.5 MPI		√	√	√	√		
	ENGINE DOHC	1.5 MPI		√	√	√	√		
ESPERO	ENGINE SOHC	1.5 MPI(BEFORE 93MY)		√	√	√	√		
		1.5 MPI(AFTER 93MY)		√	√	√	√		
		1.8 MPI		√	√	√	√		
		2.0 MPI		√	√	√	√		
		2.0 TBI		√	√	√	√		
	ENGINE DOHC	1.5 MPI(BEFORE 93MY)		√	√	√	√		
		1.5 MPI(AFTER 93MY)		√	√	√	√		
		1.5 MPFI(BEFORE 93MY)		√	√	√	√		
		1.5 MPFI(AFTER 93MY)		√	√	√	√		
	ATUTOMATIC TRANSAXLE			√	√	√			
	ANTI-LOCK BRAKE SYSTEM			√	√	√			
	SRS-AIRBAG			√	√				
PRINCE	ENGINE SOHC	1.8 MPFI		√	√	√	√		
		2.0 MPFI		√	√	√	√		
		LPG		√	√				
		2.0 (rus)							
		2.2L MPFI		√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√		√	
SUPER SALON	ENGINE SOHC	1.8 MPI		√	√	√	√		
		2.0 MPI		√	√	√	√		

SUPER SALON	ANTI-LOCK BRAKE SYSTEM			√	√	√		√	
CIELO	ENGINE SOHC	UNLEAD 1.5L		√	√	√	√		
		UNLEAD 1.8L		√	√	√			
	ENGINE DOHC	UNLEAD 1.5L		√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√			
	ANTI-LOCK BRAKE SYSTEM			√	√	√			
	SRS-AIRBAG								
NEXIA	ENGINE SOHC	UNLEAD 1.5L		√	√	√	√		
		UNLEAD 1.8L		√	√	√			
		LEAD 1.5		√	√	√	√		
		1.5(rus)		√	√	√	√		
	ENGINE DOHC	UNLEAD 1.5L		√	√	√	√		
		LEAD 1.5L		√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√			
	ANTI-LOCK BRAKE SYSTEM			√	√	√			
SRS-AIRBAG			√	√					
NEW-PRINCE	ENGINE SOHC			√	√	√	√		
	ENGINE DOHC			√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√		√	
NEW-BROUGHAM	ENGINE SOHC			√	√	√	√		
	ENGINE DOHC			√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√		√	
	ENGINE SOHC	1.3L		√	√	√	√		
		1.5L		√	√	√	√		
	ENGINE DOHC	1.5L		√	√	√	√		

LANOS	ENGINE DOHC	1.6L		√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√			
	ANTI-LOCK BRAKE SYSTEM	01.DELPHI		√	√	√	√		
		02.BOSCH		√	√	√	√		
	SRS-AIRBAG			√	√				
NUBIRA	ENGINE SOHC	1.5L		√	√	√	√		
	ENGINE DOHC	1.5L		√	√	√	√		
		1.8L		√	√	√	√		
		2.0L		√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√			
	ANTI-LOCK BRAKE SYSTEM			√	√	√			
	SRS-AIRBAG			√	√	√			
LEGANZA	ENGINE SOHC	1.8L		√	√	√	√		
		LPG		√	√				
		2.0L		√	√	√	√		
	ENGINE DOHC	1.8L		√	√	√	√		
		2.0L		√	√	√	√		
		2.2L		√	√	√	√		
		LPG		√	√				
	AUTOMATIC TRANSAXLE	LPG		√	√	√			
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	√	Air Bleed
	SRS-AIRBAG			√	√	√			
MATIZ/SPARK	ENGINE CONTORL	01.UNLEADED		√	√	√			
		02.LEAD		√	√	√			
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
		SRS-AIRBAG			√	√			

NUBIRI II	ENGINE SOHC	2.0 L		√	√	√	√		
	ENGINE DOHC	1.5 L		√	√	√			
		1.6 L		√	√	√			
		2.0 L		√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√			
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
SRS-AIRBAG			√	√	√				
MAGNUS	ENGINE CONTROL	GASOLINE(L4)		√	√	√	√		
		XK(SIEMENS L6)		√	√	√			
		LPG		√	√				
	AUTOMATIC TRANSAXLE	GASOLINE(~2002MY)		√	√	√	√		
		GASOLINE(2002MY~)		√	√	√	√		
		LPG		√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
SRS-AIRBAG			√	√					
ISC			√	√	√	√			
REZZO/TACUMA	ENGINE CONTROL	UNLEADED		√	√	√	√		
		LPG		√	√				
	AUTOMATIC TRANSAXLE	GASOLINE		√	√	√	√		
		LPG		√	√	√	√		
		4HP16		√	√	√	√		
	SAISIN		√	√	√	√			
ANTI-LOCK BRAKE SYSTEM			√	√	√	√			
SRS-AIRBAG			√	√	√				
KALOS/AVEO(~0	ENGINE CONTROL			√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√	√		

5MY)	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
	SRS-AIRBAG			√	√				
DAMAS/RABO	ENGINE CONTROL			√	√	√	√		
LACETTI/OPTRA/ EXCELLE(~05)	ENGINE CONTROL	1.5L		√	√	√			
		1.6L		√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
	SRS-AIRBAG			√	√				
KALOS/AVEO(06 ~)	ENGINE CONTROL		√	√	√	√	√		
	AUTOMATIC TRANSAXLE		√	√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
	SRS-AIRBAG			√	√				
LACETTI/OPTRA/ EXCELLE(06~)	ENGINE CONTROL	1.5 DOHC (SIEMENS)		√	√	√	√		
		1.6 DOHC (SIEMENS)		√	√	√			
		2.0L DIESEL		√	√				
	AUTOMATIC TRANSAXLE		√	√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM		√	√	√	√	√		
SRS-AIRBAG			√	√					
MATIZ(M200)	ENGINE CONTROL	0.8 SOHC	√	√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM		√	√	√	√	√		
	SRS-AIRBAG			√	√				
		GASOLINE 1.8L		√	√	√			LEARNING DATA RESET
		GASOLINE 2.0L/2.5L		√	√	√			LEARNING DATA RESET

TOSCA	ENGINE CONTROL	LPI(EMS ECU)		√	√	√	√		
		LPI(IFB ECU)		√	√	√	√		
		LPP 2.0L(MAIN)		√	√	√			LEARNING DATA RESET
		LPG 2.0L(INTERFACE)		√	√	√			
		2.0L DIESEL		√	√	√			
	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(GAS 1.8L)		√	√	√			
		AISIN 4 GEAR(LPG 2.0L)		√	√	√			
		AISIN 5 GEAR(GAS 2.0/2.5L)		√	√	√			
		AISIN TCU(DIESEL)		√	√	√			
	ANTI-LOCK BRAKE SYSTEM			√	√	√			
SRS-AIRBAG		√	√	√	√				
ISU			√	√	√				
GENTRA	ENGINE CONTROL	1.2 SOHC (SIEMENS)		√	√	√			
		1.6 DOHC (DELPHI)		√	√	√			
		1.5 SOHC	√	√	√	√	√		
	AUTOMATIC TRANSAXLE		√	√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√		
SRS-AIRBAG		√	√	√	√				
STATEMAN	ENGINE CONTROL	V6		√	√	√	√		
		V6 OBD		√	√	√			
	AUTOMATIC TRANSAXLE			√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM	ABS		√	√	√	√		
		ABS/ETC(DISABLE)		√	√	√			
	SRS-AIRBAG			√	√	√			
	BODY CONTROL SYSTEM	INSTRUMENT		√	√	√			
TRIP COMPUTER			√	√	√				
INSTRUMENT - CONFIG			√	√	√				

WINSTORM/CAPTIVA	ENGINE CONTROL			√	√	√			LEARNING DATA RESET
	AUTOMATIC TRANSAXLE			√	√	√			LEARNING DATA RESET
	ANTI-LOCK BRAKE SYSTEM			√	√		√		SAS SENSOR ZERO SETTING

(*) : Tested;

(?) : Manual on website(www.x431.com)

Note: The final interpretation of the products belongs to LAUNCH TECH CO., LTD.

CONNECTOR	X431	DIAGUN
SMART OBD	Use for the cars of 16-PIN Diagnostic socket	N/A
DAEWOO-12	Use for the cars of 12PIN Diagnostic socket	Use for the cars of 12PIN Diagnostic socket
OBD 16C	N/A	N/A
CANBUS II	N/A	N/A
diagun connector	N/A	Use for the cars of 16-PIN Diagnostic socket
SUPER 16	Use for the cars of 16-PIN Diagnostic socket	N/A